



THE T50®

HEAVY DUTY TACKER GUN

ITEM UPC: 079055000501



T50® MAINTENANCE:

- #1 - Remove pusher rod from rear of T50
- #2 - Remove screw and nut from rear of T50 channel
- #3 - Pull down entire inside frame for complete cleaning
- #4 - Reassemble T50

T50® USAGE/LOADING INSTRUCTIONS:

- #1 - Remove pusher rod from rear of T50
- #2 - Insert strip of staples
- #3 - Replace pusher rod

